

# Slip Sheet Recapture Program

**Decrease your disposal costs and generate income from waste.**  
**Help protect the environment.**

## STEP 1 Create a recycle bin

- Construct a bin to hold a pallet, approximately 56"L x 45"W x 53"H.
- Place a 40" x 48" wood or plastic pallet at the bottom.



## STEP 2 Stack slip sheets

- Remove all paper, cardboard or any other foreign materials from between the slip sheets. All contaminants must be removed!
- Stack slip sheets between 3 and 4 feet high, packing them tightly to ensure stability.



## STEP 3 Secure slip sheets to the pallet

- Once a 3-4 foot high stack is completed, secure the slip sheets to the pallet using 2 evenly-spaced steel or polyester straps.
- Do not use rope, wire or other alternative packaging materials.



## STEP 4 Remove and recycle the finished pallet

- Remove the finished pallet from the bin. Add 2 straps crosswise to the previously applied straps. If possible, stretch wrap the pallet load.
- When at least 7 skids are completed, call ITW Plastic Packaging at 419-334-6918 to request a pick-up. ITW will arrange transportation from your location.

