

Slip Sheet Recapture Program

Decrease your disposal costs and generate income from waste.
Help protect the environment.

STEP 1 **Create a recycle bin**

- Construct a bin to hold a pallet, approximately 56"L x 45"W x 53"H.
- Place a 40" x 48" wood or plastic pallet at the bottom.



STEP 2 **Stack slip sheets**

- Remove all paper, cardboard or any other foreign materials from between the slip sheets. All contaminants must be removed!
- Stack slip sheets between 3 and 4 feet high, packing them tightly to ensure stability.



STEP 3 **Secure slip sheets to the pallet**

- Once a 3-4 foot high stack is completed, secure the slip sheets to the pallet using 2 evenly-spaced steel or polyester straps.
- Do not use rope, wire or other alternative packaging materials.



STEP 4 **Remove and recycle the finished pallet**

- Remove the finished pallet from the bin. Add 2 straps crosswise to the previously applied straps. If possible, stretch wrap the pallet load.
- When at least 7 skids are completed, call ITW Plastic Packaging at 419-334-6918 to request a pick-up. ITW will arrange transportation from your location.

